

# Installation Instructions for the Road King Savior250psi Compressor

1) Remove seat.

2) Install compressor cradle bracket . Some 2003 and newer models has 2 ground wires. If so remove both nuts and wire. Install cradle then re install wire and nuts. If not install 1/4 ex bolt see picture

3) Install compressor with piston head to the left . Motor will fit in cradle. Tighten hose clamp firm in place. Turn white gear by hand to make sure it terns freely if the crank shaft touches any part of the frame just move the bracket to the left till clear and re tighten bracket. See picture.

4) Unplug white wire fitting on motor. Plug wire assembly in kit into accessory outlet just in front of battery. Install extra ground wire from motor to the battery ground flip the accessory switch to test. Compressor should start.

5) Tread hose through 1 inch hole in frame.

6) Remove tie down strap from block. Remove rubber cap and nuts from fitting outlet. Split block by puling back. There is a small spring pin to hinge the block. Thread the hose fitting through hole . Close block push up ward to set spring pin in hole. . Hold the block firm and push the assemble through the hole. Turn the set screw 5/64 until it holds tight. Make sure the surface is flat.

7) Install rubber cap and stainless steel washer. Tighten nut firm. Trim access length of rubber cap with sharp scissors.

8) Check to make sure pressure relief valve is tight at the gauge. It could of gotten loose in shipping.

